



User's Guide to Restore an Android Smart TV to Factory Settings




Step 1 Power On the Android Smart TV and access the "Settings" Menu.




 Note that restoring your Android Smart TV to factory settings will erase all of your settings and personal data, so make sure to back up any important files before proceeding.

Step 2 Navigate to "More Settings" Option.




Step 3 Locate the "System" Section.




User's Guide to Restore an Android Smart TV to Factory Settings



Step 4 Select "Reset Options"





Step 5 Click on "Erase all data (factory reset)".



i Performing a factory reset will erase all your personal data, including installed apps, accounts, and customized settings. Make sure to back up any important data before proceeding.

Step 6 Select "Reset Device" to complete the process.



Step 7 After the factory reset is complete, your Android Smart TV will restart automatically. You'll be presented with the initial setup screen, similar to when you first got the TV. Follow the on-screen instructions to set up your TV, including connecting to your Wi-Fi network, signing in to your account, and configuring any additional settings.