




Panel Orientation Instructions (4K TV System)




1 Press the Source button
Find and press the “Source” button on the remote.
* Note: Disconnect all HDMI connections from the TV.




2 Highlight the HDMI1 input
An input source menu would pop up at the top right portion of your screen. Highlight the HDMI1 option but do not press it.
* Note: If the HDMI button is accidentally pressed, press “Exit” button and start from the beginning.




3 Press 2-0-0-8 / 2-5-8-8
Slowly press the numbers 2-0-0-8 or 2-5-8-8. This will prompt the design setting menu to pop up on the screen.




4 Press User Set
Under “Design Setting”, find and press “USER SET”.



5 Press Mirror Enable
Under “USER SET”, find and press “Mirror Enable”.



6 Set Mirror Enable to Mirror HV
Change “Mirror Enable” to “Mirror HV”. The TV screen should now be back to its normal position.



7 Press the Exit button

Press the "Exit" button to go back to main screen.