




**1** Go to main screen. Find the "Settings" icon and click it.




**2** This will be shown when you click the "Settings". Find and click the "Apps" tab.




**3** After clicking "Apps", this will be shown. Click "App permissions".




**4** Under "App permissions", find and click "Microphone".




**5** Under "Microphone permissions", you can find "Amazon Alexa". Click the toggle to turn it on and allow your TV to use the Microphone for Amazon Alexa.




**6** After successfully turning on the Microphone for Amazon Alexa, go back to "Apps" and click "System Apps".



**7** When you click "System Apps" this will show you all the installed apps in your TV. Find and click "Amazon Alexa".



**8** Under "App permissions" for Amazon Alexa, double check if the Microphone is on. If it is on, you can now exit "Settings".



**9** Done! You can now enjoy your TV with Amazon Alexa's voice control.