




# Panel Orientation Instructions (HDMI TV System)




- 1 Press the Menu Button**  
On the remote, find and press the “Menu” button.  
\* Note: Disconnect all HDMI connections from the TV.




- 2 Press 2-5-8-0**  
Slowly press the buttons 2-5-8-0. This will prompt the factory setting menu to pop up on the screen.




- 3 Press the Special Set**  
Under the “Factory Setting”, find and press “SPECIAL SET”.



- 4 Press Panel Control**  
Under “SPECIAL SET”, find and press “Panel Control”.



- 5 Press Mirror Enable**  
Find “Mirror Enable” and set it to “ON”. The TV screen should now go back to normal.



- 6 Press the Exit Button**  
Press the “Exit” button to go back to main screen.